



Median Nerve under Pressure

A U.S. Department of Labor report says that RSI (Repetitive Strain Injury) of the part above the waist (e.g. wrist, elbow, shoulder) accounts for 2/3 of the occupational diseases having been reported, among which CTS (Carpal Tunnel Syndrome) is the most often. Therefore U.S. Department of Labor declares that CTS is the main occupational disease in 2000's, and it has made employees disable in a large scale.

Around 36% of the people suffering from CTS will take a surgery. And among them nearly 50% will relapse within 6 weeks to 6 months if they do the same work as before. Only 23.12% of them will fully recover.

Symptoms of CTS







Painful Wrist Pricking Shoulder



 $\ensuremath{\mathsf{World}}$  first removable patented palm rest . Offer full support for you palm to avoid rub.

Work more precisely without the palm rest





When you work on a keyboard tray or a narrow desktop, you may remove the palm rest which occupies a larger space.

Install the palm rest to protect your palm







Work with the palm rest and your palm is protected. To get precision please move your elbow or wrist to work.

minicute®

Hello.







World first weight adjustable patented design.

Thanks for using Minicute products. Please read this manual before use.



Packing List Minicute EZmouse5 right hand wired User manual



Your health and surprise motivate us.

**MINICUTE®** 

We have been striving.

500/1000/1500/2000DPI Resolution

Mouse dimensions


Palm rest dimensions

Windows/Mac OS/linux One vacant min. USB2.0 port

1. Plug the mouse into a min. USB2.0 port. Then it is ready to use.

Common mouse makes your arm twisted.

EZmouse5 keeps your arm in a neutral position,



- 2. Adjusting weight by putting coins in it.
- 3. The button on the left is by default a backward button, when gaming it can be programmed with other functions



4. The palm rest is removable.

50mA/5V

Optical

75X72X106mm

155X99X5mm

150g







- The button on the left is by default a backward button. The one on the right near the bottom is for forward. Both buttons can be programmed with other functions.
- DPI switch and on / off switch are underneath. Resolutions are 500 / 1000 / 1500 / 2000DPI. Press DPI switch and the indicator will flash, red for 500DPI, green for 1000DPI, blue for 1500DPI, and light blue for 2000DPI.
- $\ensuremath{\mathsf{3}}.$  The slot underneath is used to adjust weight by adding coins inside.

